

2-in-1 Security Multi-Flex Stand and Magnetic Wall Mount


for 7-14 Inch Tablets

USER MANUAL

PAD-MSKMSB

**Note - Hinges may get looser and droop over time. Please tighten screws for optimum usage and efficiency.

Contents







(for Stand)



Lock x 1

(with 2 keys)



















Adjusting the Angle



Installing Your Tablet









2. Place tablet against corner then slide in until snug.

Using the Lock



1. Loop the cable around a secure object.




2. Insert the cable into the security slot.




frame and cable.

Unlock The Security Frame



1. Insert the key into the lock button to release the cable.



2. Press and hold on the release button to unlock the frame.










Mounting Tablet On The Wall

A - For wooden wall




1. Tear off adhesive film on the bottom of the bracket.




2. Stick to the wall and fix it with screws.


B - For cement wall




diameter: 6.5~7mm depth: 40~45mm



1. Drill a hole on the wall. 2. Knock the expansion 3. Fix it with screws bolts completely into on the wall. the wall.



C - For iron product



Adjusting the Joint

If the joint is loose, you can tighten it with the hexagonal wrench.

